



Figure 2.9. Typical bank failure surfaces: (a) noncohesive, (b) cohesive, and (c) composite (after Brown).⁽¹⁷⁾